

ALL MAJOR MAKES SHOCKS & STRUTS

BUYER'S
GUIDE



**MAGNETI
MARELLI**®

Offered by:
MOPAR®

Quality Auto Parts for All Major Makes

Buyer's Guide

All-Makes Magneti Marelli Offered by Mopar

Product: Shocks & Struts

For Reference Only. See Application Guide for Actual Vehicle Application and Selection of Correct Part for Vehicle

Part Number	Part Description	National Popularity Ranking (A - most popular; B; C; D - least popular New - New Part)	National Vehicles in Operation (VIO)	Vehicle Applications
1AMSH11003	Shock Absorber	A	3,952,645	Cadillac Escalade (02-06); Chevrolet Avalanche 1500 (02-06),Silverado 1500 (99-07),Suburban 1500 (00-06),Tahoe (00-06); GMC Sierra 1500 (99-07),Sierra C3 (01),Yukon (00-06),Yukon XL 1500 (00-06)
1AMSH11050	Shock Absorber	A	3,952,645	Chevrolet Silverado 1500 (99-07); GMC Sierra 1500 (99-07)
1AMSH11074	Shock Absorber	A	292,358	Chevrolet Silverado 1500 (04-07),Suburban 2500 (00-01); GMC Sierra 1500 (04-06),Yukon XL 2500 (00-01)
1AMSH12026	Shock Absorber	A	3,037,062	Cadillac Escalade (02-06); Chevrolet Avalanche 1500 (02-06),Silverado 1500 (03-07),Suburban 1500 (00-06),Suburban 2500 (00-11),Tahoe (00-06); GMC Yukon (00-06),Yukon XL 1500 (00-06),Yukon XL 2500 (00-11)
1AMSH12038	Shock Absorber	A	3,952,645	Chevrolet Silverado 1500 (99-07); GMC Sierra 1500 (99-07),Sierra C3 (01)
1AMSH12043	Shock Absorber	A	3,952,645	Chevrolet Silverado 1500 (04-07),Silverado 1500 HD (05-07); GMC Sierra 1500 (04-06),Sierra 1500 HD (05-07)
1AMSH12053	Shock Absorber	A	3,967,816	Chevrolet Silverado 1500 (99-07); GMC Sierra 1500 (99-07)
1AMSH12054	Shock Absorber	A	4,444,429	Chevrolet Blazer (95-05),LLV (87-95),S10 (95-04); GMC Jimmy (94-05),Sonoma (94-04),Syclone (91),Typhoon (92-93)
1AMSH21001	Shock Absorber	A	3,857,545	Ford Explorer (95-03),Explorer Sport Trac (01-05),Ranger (98-11); Mazda B3000 (98-07),B4000 (98-09); Mercury Mountaineer (97-01)
1AMSH21004	Shock Absorber	A	3,952,645	Chevrolet Avalanche 1500 (02-06),Silverado 1500 (99-07),Suburban 1500 (00-06),Tahoe (00-06); GMC Sierra 1500 (99-07),Sierra C3 (01),Yukon (00-06),Yukon XL 1500 (00-06)
1AMSH21010	Shock Absorber	A	4,421,714	Chevrolet Blazer (95-05),S10 (83-04),S10 Blazer (83-94); GMC Jimmy (92-05),S15 (83-90),S15 Jimmy (83-91),Sonoma (91-04); Isuzu Hombre (98-00); Oldsmobile Bravada (91-94 96-01)
1AMSH21017	Shock Absorber	A	3,807,314	Ford Expedition (97-02),F-150 (97-03),F-150 Heritage (04),F-250 (97-99)
1AMSH21023	Shock Absorber	A	3,839,220	Ford Expedition (97-02),F-150 (97-03),F-150 Heritage (04),F-250 (97-99); Lincoln Navigator (98-02)
1AMSH21030	Shock Absorber	A	1,809,705	Ford Ranger (98-11); Mazda B2300 (01-09),B2500 (98-01),B3000 (98-07),B4000 (98-06)
1AMSH21037	Shock Absorber	A	2,540,031	Ford E-150 (07),E-250 (03-07),E-250 Econoline (92-02),E-250 Super Duty (04-05),Excursion (00-05),F-250 Super Duty (99-07),F-350 Super Duty (99-07)
1AMSH21062	Shock Absorber	A	3,952,645	Chevrolet Silverado 1500 (99-07); GMC Sierra 1500 (99-07)
1AMSH21069	Shock Absorber	A	2,475,667	Ford Crown Victoria (95-02); Mercury Grand Marquis (95-02)
1AMSH22002	Shock Absorber	A	4,453,005	Chevrolet Blazer (95-05),LLV (87-95),S10 (82-04),S10 Blazer (83-94); GMC Jimmy (92-05),S15 (82-90),S15 Jimmy (83-91),Sonoma (91-04); Isuzu Hombre (96-00); Oldsmobile Bravada (91-94 96-01)
1AMSH22006	Shock Absorber	A	2,700,711	Ford Explorer (91-03),Explorer Sport Trac (01-05); Mazda Navajo (91-94); Mercury Mountaineer (97-01)

Buyer's Guide

All-Makes Magneti Marelli Offered by Mopar

Product: Shocks & Struts

For Reference Only. See Application Guide for Actual Vehicle Application and Selection of Correct Part for Vehicle

Part Number	Part Description	National Popularity Ranking (A - most popular; B; C; D - least popular New - New Part)	National Vehicles in Operation (VIO)	Vehicle Applications
1AMSH22008	Shock Absorber	A	3,494,510	Ford Bronco II (89-90),Ranger (89-09); Mazda B2300 (94-97 01-09),B2500 (98-01),B3000 (94-07),B4000 (94-06)
1AMSH22012	Shock Absorber	A	3,952,645	Chevrolet Silverado 1500 (99-07); GMC Sierra 1500 (99-07)
1AMSH22025	Shock Absorber	A	1,110,919	Buick Special (64-69),Sportwagon (64-69); Chevrolet Camaro (67-69),Chevy II (62-67); Ford Country Squire (87-91),Crown Victoria (92-02),Elite (75-76),Fairlane (66-70),Falcon (66-70),Gran Torino (72-76),LTD (79-86),LTD Crown Victoria (87-91),LTD II (77-79),Ranchero (66-79),Thunderbird (67-72 77-79),Torino (68-76); Lincoln Mark IV (72),Mark VI (80-83); Mercury Capri (71-77),Colony Park (87-91),Comet (66-69),Cougar (74-79),Cyclone (68-71),Grand Marquis (79-02),Marquis (79-82),Montego (68-76); Nissan 410 (64-65),411 (64-67),510 (68-72); Oldsmobile Vista Cruiser (64-72); Pontiac Firebird (67-69)
1AMSH22035	Shock Absorber	A	2,862,324	Ford F-150 (97-03),F-150 Heritage (04)
1AMSH22040	Shock Absorber	A	3,952,645	Chevrolet K30 (77-86),Silverado 1500 (99-07),V30 (87-88),V3500 (89-91); GMC K35 (77-78),K3500 (79-86),Sierra 1500 (99-07),Sierra C3 (01),V3500 (87-91)
1AMSH22042	Shock Absorber	A	1,968,891	Chevrolet Avalanche 1500 (02-06),Silverado 3500 (01-07),Silverado 3500 HD (07-10),Suburban 1500 (00-06),Suburban 2500 (00-11),Tahoe (00-06); GMC Sierra 3500 (01-07),Sierra 3500 HD (07-10),Yukon (00-06),Yukon XL 1500 (00-06),Yukon XL 2500 (00-11)
1AMSH22045	Shock Absorber	A	2,830,418	Ford F-150 (97-03),F-150 Heritage (04)
1AMSH22051	Suspension Strut Assembly	A	2,492,818	Chevrolet Cavalier (95-05); Pontiac Sunfire (95-05)
1AMSH22052	Shock Absorber	A	2,100,488	Chevrolet Express 3500 (96-05),K1500 Suburban (92-99),K2500 Suburban (92-99),Tahoe (95-99); GMC G3500 (96),K1500 Suburban (92-99),K2500 Suburban (92-99),Savana 3500 (96-05),Yukon (95-00)
1AMST21009	Suspension Strut Assembly	A	5,891,323	Buick Allure (05-06),Century (97-05),LaCrosse (05-09),Regal (97-04); Chevrolet Impala (00-05),Monte Carlo (00-05),Venture (97-05); Oldsmobile Intrigue (98-02),Silhouette (97-04); Pontiac Grand Prix (97-98),Montana (99-05),Trans Sport (97-98)
1AMST21033	Suspension Strut Assembly	A	2,858,868	Chevrolet Classic (04-05),Malibu (97-03); Oldsmobile Alero (99-04),Cutlass (97-99); Pontiac Grand Am (99-05)
1AMST21047	Suspension Strut Assembly	A	2,492,818	Chevrolet Cavalier (95-05); Pontiac Sunfire (95-05)
1AMST21056	Suspension Strut Assembly	A	3,707,893	Ford Taurus (00-07); Mercury Sable (00-05)
1AMST21057	Suspension Strut Assembly	A	3,707,893	Ford Taurus (00-07); Mercury Sable (00-05)
1AMST21058	Suspension Strut Assembly	A	1,716,528	Saturn SC (91-92),SC1 (93-02),SC2 (93-02),SL (91-02),SL1 (91-02),SL2 (91-02),SW1 (93-99),SW2 (93-01)
1AMST22007	Suspension Strut Assembly	A	5,399,167	Buick Allure (05-06),Century (97-05),LaCrosse (05-09),Regal (97-04); Chevrolet Impala (00-11),Monte Carlo (00-07); Oldsmobile Intrigue (98-02); Pontiac Grand Prix (97-08)

Buyer's Guide**All-Makes Magneti Marelli Offered by Mopar****Product: Shocks & Struts****For Reference Only. See Application Guide for Actual Vehicle Application and Selection of Correct Part for Vehicle**

Part Number	Part Description	National Popularity Ranking (A - most popular; B; C; D - least popular New - New Part)	National Vehicles in Operation (VIO)	Vehicle Applications
1AMST22036	Suspension Strut Assembly	A	4,261,175	Ford Taurus (00-07); Mercury Sable (00-05)
1AMST22049	Suspension Strut Assembly	A	2,773,114	Chevrolet Classic (04-05), Malibu (98-03); Oldsmobile Alero (99-04), Cutlass (98-99); Pontiac Grand Am (99-05)
1AMST22065	Suspension Strut Assembly	A	1,716,528	Saturn SC (91-92), SC1 (93-02), SC2 (93-02), SL (91-02), SL1 (91-02), SL2 (91-02), SW1 (93-99), SW2 (93-01)